



LUX LES
DOM-DEKOR

**PLEASE READ THIS PRIOR
to installing LUX LES Dom-Dekor wooden wall panels.**

WOODEN WALL INSTALLATION INSTRUCTION

Here we provide step-by-step instructions for installing all of LUX LES Dom-Dekor wooden wall panels. Instructions for each type of product are available to review and print out. In addition to obtaining excellent final results – meaning a fantastic-looking wall – it is important you follow these instructions to ensure that your product is properly protected under our warranty.

You can use any type of parquet adhesive to install LUX LES Dom-Dekor wooden wall panels. Please select a parquet adhesive based on all an any of the following factors – kind of wall finish, paints surface textures or other external factors such as temperature, humidity and chemical constituents of your wall and etc.

Installation of our wooden wall panels is not complicated. Except for parquet adhesive and accessories for a parquet adhesive you will also need a few supplies to complete the job.

- Cutting tools that may be necessary: a utility knife, handsaw, jigsaw, or miter saw.
- Other tools you may need: a tape measure, 4' level, straight edge, pencil for marking the wall and a ladder if you are installing above your height, etc.

Don't forget to use your imagination! Our panels can be installed not only horizontally but also vertically, diagonally, chevron or in any unique pattern you think of.

ATTENTION!!! Be sure to wear safety glasses and hearing protection when working on your project. Use a respirator when cutting and creating wood dust. For your protection and that of those around your work area, always think about your safety and that of those around you.

For best results, ensure the following!

LUX LES Dom-Dekor, proizvodnja, trgovina in storitve, d.o.o.

Cesta bratstva in enotnosti 039, 8330 Metlika, Republika Slovenija

matična številka: 8535574000, davčna številka: 90952367

IBAN: DE1310 0110 0121 3158 5735, in N26 Bank AG

+386 69 407 615

office@luxles.si

luxles.si



LUX LES
DOM-DEKOR



STEP 1. Prep the Wall Adequately.

Whichever parquet adhesive you use, carefully read its instruction for use and surface preparation. We recommend:

- to clean Dirt and Grime before installation of LUX LES Dom-Dekor wooden wall panels.
- to clean residual grease, grime, mildew, chalked paint or any other type of surface dirt must be cleaned from the surface because these can prevent optimal adhesive bonding.
- to make sure your wall surface is ready for the installation of LUX LES Dom-Dekor wooden wall panels.
- to make sure that walls are completely dry before applying LUX LES Dom-Dekor wooden wall panels.

This is not a complete list of surface preparation guidelines that is necessary for LUX LES Dom-Dekor wooden wall panels installation. Read carefully parquet adhesive instructions for use and surface preparation.

NO DUST! MAKE SURE THERE IS NO DUST.



Before you begin condition (acclimate) your panels to the room. With all panels in the interior space where they will be installed, stand them individually along the long edge or lay them flat with wood sticks spaced between them so that air circulates around each panel. Let stand for at least 24 hours if installation is above grade and at least 48 hours if installation is below grade level. For all below grade applications, always use a vapor barrier between the outside walls and the studs. Remove all trim. Turn off the electricity before removing all receptacle covers. Once the panels have been acclimated to the room, place your paneling around the room in an attractive arrangement of grain, pattern or color. Previewing this way is especially important when you use panels with a definite direction in the pattern. Once you have a good aesthetic sequence, number the back of the panels in the order in which they will be attached to the wall.

LUX LES Dom-Dekor, proizvodnja, trgovina in storitve, d.o.o.

Cesta bratstva in enotnosti 039, 8330 Metlika, Republika Slovenija
matična številka: 8535574000, davčna številka: 90952367
IBAN: DE1310 0110 0121 3158 5735, in N26 Bank AG

+386 69 407 615
office@luxles.si
luxles.si



LUX LES
DOM-DEKOR



STEP 2. Measure the Space.

Once clean, it is important to plan out the layout of your decorative wall panels because each home's dimensions vary so vastly.

Do a Dry Lay. Prior to beginning panel application, do a dry lay of panels on the floor of an open area. Use panels from several cartons of LUX LES Dom-Dekor wooden wall panels and arrange them according to your desired aesthetic.

Measure the space. Measure the space to calculate exactly how many panels you will require. Figure out how many boards you need.

Calculate how many boards high you can go and whether any boards will need to be cut down (along the long side to reduce the height of the board). Think through where you would want the cut boards – bottom, top, or middle of your layout.

To ensure a level installation, mark the width of the panel from the floorboard vertically up along the wall. Do this on the bottom left and bottom right of the wall. Use a level to draw a straight line or snap a chalk line between these marks. Use this as your guideline, applying the panel flush with the chalk line. Start your installation in the corner that you see first when entering the room or work your way across the wall, from left to right.



STEP 3. Place panels, cutting as you go.

Once you have got your wall planned and leveled, now you can start placing the panels in the layout you find most aesthetically pleasing. We recommend a staggered panel layout with most panel designs to create an organic flow that feels natural.

Tips. In order to stagger the panels, cut a panel down to two thirds its size and use it as your starting piece on the second row. Continue across the wall using full-length panels. Start row three with the one-third piece you have from before. Continue with full-size panels.



LUX LES
DOM-DEKOR

Tips. More Fun with a Partner. Installation of LUX LES Dom-Dekor wooden wall panels is much easier if you have a second person to help, particularly in the process of establishing a completely level starting line (first row of panels you install). If working alone, it is advisable to tap 1½" finish nails halfway into the wall, every 100mm along a 100% level starting line, to help position the panels accurately when installing horizontally.

Begin placing your panels by applying the parquet adhesive to them as directed in the instructions for your assembly parquet adhesive. Make sure you don't jump around and skip a row when placing the panels, as they are designed to be precisely interlocked together. Chances are, the panels will require a slight trim to completely cover your wall. You can cut the panels horizontally or vertically to fit the required area.

Once you are certain the adhesive is firmly in place go ahead and continue with the rest of your installation. Place your second board next to it. You are getting the idea!

Tips. Give it a couple of hours after your first board to make sure the finish of your wall does not reject the adhesive.

CUT YOUR BOARDS TO ENSURE GOOD FIT.

Congrats! You have made it to the end of the row. Carefully mark your cut and use a jigsaw, circular or power saw to make a clean cut.

Double-check all measurements before cutting panels. To cut around openings like electrical switches or outlets, turn off the power at the main panel and then remove the cover plate to the switch or outlet. You can wipe lipstick or a crayon around the rim of the box and then press the panel into place to dry fit the panel. As the panel makes contact with the box, an outline will be left on the panel from the lipstick or crayon. Place the face of the panel down and use a jigsaw to cut around the outline. Make sure that the panel opening is resting on the wall and not on the lip of the box. The cover plate will cover any gaps between the box and the opening in the panel.



LUX LES
DOM-DEKOR



STEP 4. Enjoy the Process.

Take your time with installation, use care, don't take shortcuts and appreciate both the installation process as well as your gorgeous finished wall.

Tips. MAKE STRAIGHT LINES. Make sure you are using a level to keep the boards straight.

Check it out. Congrats on your not-so-hard work! Ensure a completely secure bond and smooth surface by patting down your new decorative wall panels, no roller needed. Once your panels are fully secure, feel free to spruce them up with pictures, shelves, and other home accents.

We hope this LUX LES Dom-Dekor wooden wall panel installation guide was helpful! Now you can enjoy the stylish look of your new wall.



STEP 5. SEND US A PICTURE.

We would like to see an image of your installed wooden wall. Post pictures of your wooden wall on Instagram or Facebook and be sure to include #luxlesdomdekor so we see it! We'll share our favorites with our followers!



Questions remain.

Our knowledgeable customer service team is here to help. Please contact us if you have any additional questions about how to install your LUX LES Dom-Dekor wooden wall panels. We will patiently walk you step by step to ensure your wall panels are installed properly. Simply call us at [+386 69 407 615](tel:+38669407615) or [email us](mailto:office@luxles.si).

LUX LES Dom-Dekor, proizvodnja, trgovina in storitve, d.o.o.

Cesta bratstva in enotnosti 039, 8330 Metlika, Republika Slovenija
matična številka: 8535574000, davčna številka: 90952367
IBAN: DE1310 0110 0121 3158 5735, in N26 Bank AG

+386 69 407 615
office@luxles.si
luxles.si



LUX LES
DOM-DEKOR

How to make wood panel walls Look Good with LUX LES Dom-Dekor panels.

LUX LES Dom-Dekor wooden wall panels are here to walk you through making your wood panel walls stand out and look extraordinary. These do's and don'ts may prove vital to your next wood accent project. Our wooden wall panels make it simple to transform any room into something special. Read through these tips to make your home's interior unique with a look of seamless craftsmanship.

Think Outside the Box.

While installing wood paneling makes for an awesome accent wall, that is not the only place it can be used. Try incorporating a cool new look to your ceiling, cabinets, etc. The options are limitless! With their ease of installation, LUX LES Dom-Dekor wooden wall panels are perfect for the imaginative DIY-er.

Non-Boring Interior.

If your interior is loaded with neutral colors, there can be the danger of style boredom. Break free of a lifeless motif by installing wood panel accents in richer, more vibrant hues. The beauty of woodgrain lends interest and an infusion of unique character. Rejuvenate your space easily and affordably.

Take it in a Different Direction.

Most of us assume that wood paneling should be installed horizontally. It is nice. Your wooden panels can go anyway you please! This includes vertical, diagonal, patchwork, chevron or however else you can think of. Banish the boring and transform the typical into something creative and distinctly yours.

Do not Lose Your Outlets.

Before you install LUX LES Dom-Dekor wooden wall panels, be sure to mark the location of your wall's power outlets. We recommend outlining them on the panels before removing the paper lining covering the adhesive. Cut them out and do a trial fit before removing the lining and installing. For small-area cuts, drill a starter hole before continuing with a jigsaw or scroll saw.



LUX LES
DOM-DEKOR

Refer to our LUX LES Dom-Dekor wooden wall panels Installation Instructions for a complete guide to the proper use of our products. Our main pro tips:

- Dry-lay your panels out, using panels from several cartons, before beginning to put them up. This will give you the opportunity to arrange the panels, which vary beautifully with irregular woodgrain knots and marks, and plan your installation design for the best appearance.
- If doing a horizontal installation on a wall, it is very important to establish a 100% level starting line for the first panel. To help ensure an absolutely straight starter line with the first panel, we recommend you tap 1½" finish nails halfway into the wall, every 100 mm along the starting line.
- Position the panels before you apply a parquet adhesive. Once the adhesive is in contact with the wall surface, the panels cannot be easily moved or adjusted.

LUX LES Dom-Dekor wooden wall panels are nearly maintenance free. But to keep them looking beautiful year in and year out, damp wipe.

We recommend oiling the panels one time in two years to keep the look fresh.

If you have any question that is not addressed in our guide, contact us.
Our team members are ready to assist you.

LUX LES Dom-Dekor, proizvodnja, trgovina in storitve, d.o.o.

Cesta bratstva in enotnosti 039, 8330 Metlika, Republika Slovenija

matična številka: 8535574000, davčna številka: 90952367

IBAN: DE1310 0110 0121 3158 5735, in N26 Bank AG

+386 69 407 615

office@luxles.si

luxles.si